

# SPITFIRE - MAIN PARTS AND FRAMES BUILDING SCHEDULE

## FINISHING THE FUSELAGE



1) Fit the noseblock, **BUT DO NOT GLUE IT IN PLACE!** Sand it to match the fuselage to the profile shown on the plan. NB The very front nose block piece (NB1) should be sanded to a round profile on the front face to match the spinner disc later on.



2) Sand the fuselage all over to remove the burnt edges of the parts. Be careful not to over sand and ruin the profile of the formers, especially around the cockpit area.



3) Carefully cut out the section of the keel in the cockpit position between F7 and F8, then set the fuselage and nose block aside.