



SE5A - MAIN PARTS AND FRAMES BUILDING SCHEDULE


THE FIN & RUDDER




1) Identify and remove all of the parts on the laser cut sheets: FR1-FR9.




2) From the stiff 1.6mm square strip, cut a length for the base rib (which eventually sits on top of the fuselage) and set it aside.




3) From the light 1.6mm square strip, cut all of the ribs using the plan to get the right length. Set these aside.




4) Pin down the fin and rudder central spar FR1.



5) Lay out the parts starting at FR2 and work round in each direction, making any small adjustments as required. When you are satisfied, glue all the parts in position making sure that you have nice neat butt joints. Allow this outline to set.



6) Once the outline is set, glue all of the remaining ribs in place adjusting the length if necessary.



7) Leave to set, then remove from the board and give both sides as well as the outside edges a light sand. Be careful so as not make the structure too thin or cause unevenness in the surface by over sanding.